



DF-C 63XXX & 61XXX Series AC Laboratory Power Supplies User's Manual

by DSC-Electronics Germany • Georgstraße 36 • 53111 Bonn

1. Connection

Our devices are pre-configured to the power grid chosen with order (if not specified otherwise, our devices are manufactured for the EU power grid 230V 50Hz / 400V 50Hz). Subsequent adjustment after delivery is not possible. Connecting the device to an unsuitable power source will void any warranty.

1 Phase / EU Power Grid	
Voltage (Recommended)	230V ± 10% AC
Voltage (Max.)	250V AC
Frequency	50Hz - 60Hz
Circuit breaker minimum requirements	The maximum current of the device shall be determined as follows: $I = (\text{maximum power of the device} / 230) + 2$
1 Phase / American Power Grid	
Voltage (Recommended)	115V ± 10% AC
Voltage (Max.)	130V AC
Frequency	50Hz - 60Hz
Circuit breaker minimum requirements	The maximum current of the device shall be determined as follows: $I = (\text{maximum power of the device} / 115) + 4$

3 Phase / EU Power Grid (TN-S Network)	
Voltage (Recommended)	380V - 410V
Voltage (Max.)	430V
Frequency	50Hz
Circuit breaker Minimum requirements	The maximum phase current of the device shall be determined as follows: $I = ((\text{maximum power of the device} / 400) / 1,73) + 2$

2. General

Please read through and understand this Operation Manual before operating the product. After reading always keep the manual nearby so that you may refer to it as needed. When moving the product to another location, be sure to bring the manual as well.

Calibration

Before shipment, the instrument has been calibrated carefully in our factory. The calibration procedures and standards are compliant to the national regulations and standards for electronic calibration. If you have requested a certificate with your order, this is enclosed with your device. With ordered off-site calibration (DaKKS) the calibration was not performed in-house, please refer to the laboratory calibration protocol for details.

Warranty

We guarantee that the instrument has undergone a strict quality test before shipment and has passed all prescribed functional tests. We provide our customers with a warranty period of three years from receipt of the device. During the warranty period, all repairs, as well as spare parts are always free of charge. The warranty is void in the case of defects which have been caused by user's fault, or in case of unauthorized opening.

2.1 Safety Instructions

This chapter contains important safety instructions that you must follow when operating the instrument and when keeping it in storage. Read the following before any operation to insure your safety and to keep the device in a proper condition.

Safety Symbols

The following safety symbols may appear in this manual or on the instrument:



WARNING

Identifies conditions or practices that could result in injury or loss of life.



CAUTION

Identifies conditions or practices that could result in damage to the instrument or to other properties.



DANGER

High Voltage



ATTENTION

Refer to the Manual



Protective Earth (PE)



Earth (Ground)

2.2 Safety Guidelines

Please follow the safety guidelines when using and putting the device into operation in order to prevent safety risks and to ensure the correct operation of the product.

- **Before connecting the device to the local power supply, make sure that the device is switched off.**
- **Check if the product is compatible with the local power supply before connecting it.**
- **Be careful on the correct earthing of the device (PE connection)**
- **Do not use the product in humid environments**
- **Do not touch the output terminals of the product with unprotected hands while it is switched on.**
- **Do not use the device in extremely dusty rooms**
- **Do not use the device outside the parameters specified in the data sheet**

2.3 Unpacking and Examination

Our products are delivered carefully packed in cardboard boxes or in wooden crates, depending on place of destination and the type of the device (dimensions, weight). We pay attention to the environmental compatibility of the upholstery and packaging materials used and ask you to dispose the filling material correctly if present.

Please unpack the device and check the packaging as well as the product for transport damage. Should you notice any damage to the packaging or the device, we ask you to log it with photos and inform us immediately.

ATTENTION: If the device has been delivered in a wooden box, please do not dispose it as it can be used for eventual return transport for service procedures. Also the packaging material of smaller devices can be stored in order to be used if necessary for a return transport.

3. Operation Instructions

3.1 Front Panel Description 63XXX Series




Fig.1: Front Panel 63XXX Series (CV Version)

Nr.	Name	Description
1	Voltage Phase A	Voltage set or actual value of Phase A
2	Voltage Phase B	Voltage set or actual value of Phase B
3	Voltage Phase C	Voltage set or actual value of Phase C
4	Current / Power Ph. A	Current set or actual value of Phase A
5	Current / Power Ph. B	Current set or actual value of Phase B
6	Current / Power Ph. C	Current set or actual value of Phase C
7	Display Mode	Active „A“ LED indicates the current value Active „kW“ LED indicates the power value No active LED indicates the power factor value
8	Frequency	Output frequency „Hz“
9	Output On/Off Key	Indicates the output status
10	Float + Hot-Key	Higher the value by X percent
11	Float - Hot-Key	Lower the value by X percent
12	LV / FS Key	Switch between Low Voltage range (0 – 150V) and Full Scale range (0 – 300V)
13	Frequency Key	Fast switch between 50Hz / 60Hz
14	Setup Key	Output value setup
15	Start Key	Output ON
16	Increase Key	Higher the value
17	Decrease Key	Lower the value
18	Stop Key	Output OFF
19	Display Mode Switch Key	Toggle between Current, Power of Power Factor display

3.2 Front Panel Description 61XXX Series




Fig.2: Front Panel 61XXX Series (CV Version)

No.	Name	Description
1	Frequency	Output frequency „Hz“
2	Voltage	Voltage set or actual value
3	Current	Current actual value
4	Power / Power Factor	Power or Power Factor display
5	Display Mode	Active „A“ LED indicates the current value Active „kW“ LED indicates the power value No active LED indicates the power factor value
6	Connections	Secondary connections with universal socket
7	Power On/Off Key	Power On/Off the power supply
8	Setup Key	Output value setup
9	UP Key	Higher value
10	DOWN Key	Lower value
11	+10% Hot-Key	Higher value by 10 percent
12	-10% Hot-Key	Lower value by 10 percent
13	LV / FS Key	Switch between Low Voltage range (0 – 150V) and Full Scale range (0 – 300V)
14	Frequency Key	Fast switch between 50Hz / 60Hz
15	Start Key	Output ON
16	Stop Key	Output OFF
17	Display Mode Switch Key	Toggle between Current, Power or Power Factor display

3.3 Power ON

Set the „ON / OFF“ switch to the ON position to turn on the device. The device is equipped with a soft-start delay which slowly charges the capacities in the power supply to limit the high inrush currents. After about 10 seconds, the power supply will switch into stand-by mode.

3.3.1 Stand-By Mode

The output is switched off in stand-by mode and the device is ready to set the desired output values. The displays show a voltage of 0V and a current of 0A, which corresponds to the actual values at the output.

Press the SET button once to enter the setup menu.

Press the SET button once

- FREQUENCY display flashes -> Frequency setting

Press the SET button 2x

- VOLTAGE display flashes -> Voltage setting

Press the SET button 3x

- VOLTAGE display flashes -> FLOAT + percentage setting (default 10%)

Press the SET button 4x

- VOLTAGE display flashes -> FLOAT- percentage setting (default -10%)

Press the SET button 5x

- CURRENT display flashes -> Setting of Over Current Protection value
(In the range 0 - max. output current of the power supply / max. 0 - 50A)

Press the SET button 6x

- Save settings, back to stand-by mode

3.3.3 Setup Menu (CV Version) DF-C61XXX

Press the SET button once to enter the setup menu.

Press the SET button once

- FREQUENCY display flashes -> Frequency setting

Press the SET button 2x

- VOLTAGE display flashes -> Voltage setting

Press the SET button 3 x

- CURRENT display flashes -> setting of the Over Current Protection value
(In the range 0 - max. output current d of the power supply / max. 0 - 50A)

Press the SET button 4x

- Save settings, back to stand-by mode

3.3.4 Setting the output values for constant current sources of the DF-C series (CC version)

Constant current sources of the DF-C series which work in CC mode have no setup menu and a simplified Control panel. If you are in stand-by mode (output OFF), values can be entered directly using the arrow keys, saving is not necessary.

3.3.5 Voltage Range Setting (LV / FS)

Press the LV / FS key to switch between the voltage ranges, the currently set voltage range is displayed on the frequency display for 3 seconds with L for LV and F for FS. Normally the range is LV for 0 - 150V and FS for 0 - 300V, this may differ for custom-made devices.

4. Optional: Analogue In- / Outputs

Devices of the DF-C series can optionally be equipped with analogue inputs / outputs for setting and reading the output parameters. The analogue outputs / inputs are accessible via a labeled terminal block which is located either on the back, the front or behind the service door (depending on device model). The pin assignment is explained on the terminal block for a simple and straight forward connection.

4.1 Optional: Ext. Output On/Off Ctrl. & Interlock

Input for controlling the status of the output of the laboratory power supply (on / off), switchable as "Interlock" or external control. This input is configured as a two pin connection, a „true“ state is triggered by shorting the two pins and a „false“ state is triggered by removing any connection between the two pins of the input.

This option can be configured as either an interlock input, which disables the output of the power supply if the state is false, or as an external output status control which enables or disables the output of the power supply depending on the control signal state (true = on/false = off) if the „Output On/Off“ switch of the power supply is always in the ON position.

4.2 Optional: Potential-free output / configurable output

The output of DF-C series devices in the basic version has a potential to PE, which follows the usual protection regulations. All models can also be ordered in the following modifications (please see the „DF-C Series Function and Wiring Diagram“ PDF for details):

1). Configurable output without ELCB

The output of the power supply has no potential to the input (PE), so the output of the device has no protective earth for loads that may require a PE connection and the load is not protected by a ELCB ! By bridging output N to input N, the output can be pulled to the input potential, in this case input PE = output PE and the load is protected by the ELCB installed in the operation environment (Laboratory).

2). Configurable output with built-in ELCB

The model with integrated ELCB offers the following switchable configurations:

A). Potential-free output with its own ELCB

Connections output

L (1, 2, 3): Phase (potential-free)

N: Neutral conductor (potential-free)

GND: In this configuration to use as PE connection for the load

Remark: ELCB triggers as soon as a residual current flows through the GND conductor.

Connections input

L1: Input phase 1

L2: Input phase 2

L3: Input phase 3

N: Neutral conductor

PE: Earth conductor

B). Output with potential to input (potential to input PE)

Connections output

L (1, 2, 3): Phase

N: Neutral → Bridge to input N

GND: Do not connect

Connections input

L1: Input phase 1

L2: Input phase 2

L3: Input phase 3

N: Neutral conductor

PE: Earth conductor

5. Optional: Digital Connections


The DF-C Series can be equipped with digital connections to read / write output values in real-time through a proprietary open protocol (RS232) or Modbus (RS485).

1). RS232 Option

The RS232 connection uses our proprietary well documented protocol for easy integration into any infrastructure. The connection is established through a D-SUB 9 Pin male socket on the side of the device. The pin-out meets the defined standard characteristics of the RS232 over D-SUB standard.

2). RS485 & RS232 Option

The RS232 connection uses our proprietary well documented protocol for easy integration into any infrastructure, while the RS485 connection supports the Modbus protocol (both documented at the end of this manual). Both connections are accessible through a single D-SUB 9 Pin male socket on the side of the device. The pin-out is as follows:



Pin 2: RxD (RS232)

Pin 3: TxD (RS232)

Pin 5: Signal Ground (RS232 & RS485)

Pin 6: 485 + (RS485)

Pin 7: 485 - (RS485)

6. Connection of the load

Depending on the model the output / input connections are located on the back, on the front or behind the service door of the device. We recommend protecting the connectors from wear if the load will be frequently connected and disconnected by connecting it not directly to the device, but to use an intermediate bridge. In this case, the intermediate bridge can remain connected to the power supply - so the connection terminal of the power supply is used less often.

Interface: RS-485

Command format: Modbus-RTU

Baud rate: 9600

Communication mode: One start bit, eight data bits, two stop bits

Termination: Each command sent by the power supply as reply is terminated with a “,”

1. Command Frame

1.1 Read Device Register (Function Code 0x03)

1.1.1 Command frame sent

Command sample: 64 03 00 00 00 01 8D FF

CRC for 64 03 00 00 00 01 = FF8D

No.	Code	Data	Description
1	Device address	0x64	HEX 0x64=Value 100
2	0x03	0x03	Function code of reading register
3	High byte of address of the first register	0x00	Address of the first register
4	Low byte of address of the first register	0x00	
5	High byte of number of registers	0x00	Number of registers
6	Low byte of number of registers	0x01	
7	CRC16 check high bytes	0x8D	CRC check data
8	CRC16 check low bytes	0xFF	

1.1.2 Command frame returned

No.	Code	Data	Description
1	Device address	0x64	HEX 0x64=Value 100
2	0x03	0x03	Function code of reading register
3	Data length (M)		
4	Data of the first reading register		
...	...		
...	Data of the last reading register		
M+4	CRC16 check high bytes		CRC check data
M+5	CRC16 check low bytes		

If the address of the first register or the number of registers is incorrect, device returns the following reply:

64 83 02 D0 EE
CRC for 64 83 02 = EED0

No.	Code	Data	Description
1	Device address	0x64	HEX 0x64=Value 100
2	0x83	0x83	Function code
3	0x02	0x02	Address error code
4	CRC16 check high bytes	0xD0	CRC check data
5	CRC16 check low bytes	0xEE	

1.2 Write Device Register (Function Code 0x06)

1.2.1 Write data into a single device register

Command sample: 64 06 00 0D 04 4C 12 C9
CRC for 64 06 00 0D 04 4C = C912

No.	Code	Data	Description
1	Device address	0x64	HEX 0x64=Value 100
2	0x06	0x06	Function code of writing register
3	High byte of register address	0x00	Address of the first register
4	Low byte of register address	0x0D	
5	High byte of data	0x04	Data
6	Low byte of data	0x4C	
7	CRC16 check high bytes	0x12	CRC check data
8	CRC16 check low bytes	0xC9	

Device Return (Write Successfully):

64 06 00 0D 04 4C 12 C9
CRC for 64 06 00 0D 04 4C = C912

If the command is found to be correct, the device will return the command and execute.

1.2.2 If the address of the register is incorrect, device returns as followed:

64 86 02 D3 BE
CRC for 64 86 02 = D3BE

No.	Code	Data	Description
1	Device address	0x64	HEX 0x64=Value 100
2	0x86	0x86	Function code
3	0x02	0x02	Address error code
4	CRC16 check high bytes	0xD3	CRC check data
5	CRC16 check low bytes	0xBE	

1.2.3 If the written data was out of execution range, device returns as followed:

64 86 03 12 7E
CRC for 64 86 03 = 7E12

No.	Code	Data	Description
1	Device address	0x64	HEX 0x64=Value 100
2	0x86	0x86	Function code
3	0x02	0x03	Data error code
4	CRC16 check high bytes	0x12	CRC check data
5	CRC16 check low bytes	0x7E	

2. Device Register Address

Remarks:

- 1). All parameters are UINT two-byte data, begin with high byte and end with low byte.
- 2). Access rules of register: R=read only, W=write only, R/W=read and write.

No.	Parameter	Data Type	Unit	Access Rule	Register Address	Description
1	Status of device	UINT		R	0x0000	Working status query
2	Output frequency	UINT	0.1Hz	R	0x0001	Output parameter query
3	A-phase output voltage	UINT	0.1V	R	0x0002	
4	B-phase output voltage	UINT	0.1V	R	0x0003	
5	C-phase output voltage	UINT	0.1V	R	0x0004	
6	A-phase output current	UINT	0.1A 0.01A	R	0x0005	
7	B-phase output current	UINT	0.1A 0.01A	R	0x0005	
8	C-phase output current	UINT	0.1A 0.01A	R	0x0007	
9	A-phase output active power	UINT	0.01kW	R	0x0008	
10	B-phase output active power	UINT	0.01kW	R	0x0009	
11	C-phase output active power	UINT	0.01kW	R	0x000A	
12	A-phase output power factor	UINT	0.001	R	0x000B	Only available with customized device
13	B-phase output power factor	UINT	0.001	R	0x000C	
14	C-phase output power factor	UINT	0.001	R	0x000D	
15	High range and low range status	UINT		R	0x000E	
16	Control command	UINT		W	0x0012	
17	Frequency setting	UINT		R/W	0x0013	
18	Voltage setting	UINT		R/W	0x0014	

3 Description of Parameters

3.1 Status of device

No.	Data	Remarks	No.	Data	Description
1	0x0000	Standby mode	5	0x0004	Over temperature alarm
2	0x0001	Started mode	6	0x0005	Over current alarm
3	0x0002	Setting mode			
4	0x0003	Short circuit alarm			

3.2 Output frequency

Unit: 0.1Hz

Example: Data returned as 0x0258

HEX 0x0258 = Value 600, the output frequency of device is 60.0Hz

3.3 Output voltage

Unit: 0.1V

Example: Data returned as 0x044C

HEX 0x044C = Value 1100, the output voltage of device is 110.0V

3.4 Output current

Unit: 0.1A or 0.01A

Example: Data returned as 0x00D0

If the output capacity of the device is higher than 15KVA, the unit is 0.1A HEX 0x00D0 = Value 208, the output current of device is 20.8A.

If the output capacity of the device is lower than 15KVA, the unit is 0.01A HEX 0x00D0 = Value 208, the output current of device is 2.08A.

3.5 Output power

Unit: 0.01kW

Example: Data returned as 0x00E4

HEX 0x00E4 = Value 228, the output active power of device is 2.28kW

3.6 High range and low range status

No.	Data	Description
1	0x01	High range
2	0x00	Low range

3.7 Frequency setting

Unit: 0.1Hz

This parameter has write access.

Example: Set output frequency 62Hz, write 0x026C in register address 0x13

Command sample: 64 06 00 13 02 6C 70 B7

HEX 0x026C = Value 620

CRC for 64 06 00 13 02 6C = B770

3.8 Voltage setting

Unit: 0.1V

This parameter has write access.

Example: Set output voltage 120V, write 0x04B0 in register address 0x14.

Command sample: 64 06 00 14 04 B0 C3 4F

HEX 0x04B0 = Value 1200

CRC for 64 06 00 14 04 B0 = 4FC3

3.9 Control commands

No.	Data	Description
1	0x0000	Output stop
2	0x0001	Output start
3	0x0002	
4	0x0003	Switch to low range
5	0x0004	Switch to full range

Remarks:

- 1). 0x0000 can be executed under any status
- 2). 0x0001 can be executed only under standby mode
- 3). Voltage can not be set across the range when output is started

Communication Protocol for DF-C63XXX Series Power Supplies

Interface: RS-232 (D-SUB)

Command format: Asynchronous, 1 start bit, 8 data bits, 1 stop bit

Baud rate: 9600

Communication mode: ASCII code, "X" stands for numbers.

Termination: Each command sent by the power supply as reply is terminated with a ";

Command	Function	Response	Description
#G	Output START	Received	The command is accepted
		Error	The power supply is not in standby mode or output may be already active
#U	Output STOP	Received	The command is accepted
		Error	The power supply output is not active
#D	Read the output status	XXX.XHz;A:XXX.XV XXX.XAXX.XXkW; B:XXX.XV XXX.XAXX.XXkW; C:XXX.XV XXX.XAXX.XXkW	The reply is a sequence of output frequency, voltage, current and power. For example: 060.0Hz;A:090.0V010.0A00.90kW;B:090.0V010.0A00.90kW;C:090.0V010.0A00.90kW.
		Error	The power supply output is not active
#SXXXX XXXX (S followed by 8 data digits.)	Set the output parameter. The first 4 digits are the frequency value (resolution 0.1Hz). The last 4 digits are the voltage setting (resolution 0.1V). The number "0" cannot be omitted in the command. For example setting the parameters 101Hz 62V would result in: #S10100620	Received	The command is accepted
		Error	The power supply is not in standby mode, or the parameter exceeds range
#H	Switch to FS (0 – 300V) mode	Received	The command is accepted
		Error	Wrong command
#L	Switch to LV (0 – 150V) mode	Received	The command is accepted
		Error	Wrong command
#R	STOP output and CLEAR alarm	Received	The command is accepted
#C	Read the status of the power supply	000	Standby mode
		001	Started
		002	Setup mode
		005	Short circuit alarm
		006	Over temperature alarm
		007	Over current alarm

Communication Protocol for DF-C61XXX Series Power Supplies

Command	Function	Response	Description
#G	Output START	Received	The command is accepted
		Error	The power supply is not in standby mode or output may be already active
#U	Output STOP	Received	The command is accepted
		Error	The power supply output is not active
#D	Read the output status	XXX.XHzXXX.XV X.XXXAXXXX.XW	The reply is a sequence of output frequency, voltage, current and power. For example: 050.0Hz110.2V0.950A0099.5W
		Error	The power supply output is not active
#SXXXX XXXX (S followed by 8 data digits.)	Set the output parameter. The first 4 digits are the frequency value (resolution 0.1Hz). The last 4 digits are the voltage setting (resolution 0.1V). The number "0" cannot be omitted in the command. For example setting the parameters 101Hz 62V: #S10100620	Received	The command is accepted
		Error	The power supply is not in standby mode, or the setting parameter exceeds range
#H	Switching to FS (0 – 300V) mode	Received	The command is accepted
		Error	Wrong command
#L	Switching to LV (0 – 150V) mode	Received	The command is accepted
		Error	Wrong command
#R	STOP output and CLEAR alarm	Received	The command is accepted
#C	Read the status of the power supply	000	Standby mode
		001	Started
		002	Setting mode
		005	Short circuit alarm
		006	Over temperature alarm
		007	Over current alarm